

ASSEMBLY OF BALL BEARING/SOFT CLOSE RUNNER BEDROOM DRAWER BOX

BEDROOM DRAWER BOX WILL CONSIST OF;

FOUR 18MM THICK SIDES

ONE 8MM THICK BASE

2 OF THE SIDES WILL BE OF THE SAME LENGTH WITH RUNNERS ALREADY ATTACHED. THESE SIDES WILL BE THE LEFT AND RIGHT SIDES OF YOUR DRAWER BOX. THE OTHER 2 SIDES THEN WILL BE THE FRONT AND BACK OF YOUR DRAWER BOX.

PLACE THE LEFT AND RIGHT SIDES IN PARALLEL WITH EACH OTHER. MAKE SURE THAT WHEN PLACING THE SIDES IN PARALLEL WITH EACH OTHER THAT THE GROOVE LINES ARE FACING INWARDS/EACH OTHER AND THE BLACK CLIP ON THE RUNNER IS TOWARDS THE BACK OF THE DRAWER BOX.

TAKE ONE OF THE OTHER 2 SIDES AND PLACE IT IN BETWEEN THE LEFT AND RIGHT SIDE, AGAIN WITH THE GROOVE LINE FACING INWARDS. PLACE THIS AT THE BACK OF THE DRAWER BOX. THE GROOVE LINES SHOULD ALL BE CONTINUOUS; FROM LEFT SIDE, TO BACK, TO RIGHT SIDE.

WITH 45MM SCREWS PROVIDED (LONGEST ONES), SCREW THE TWO SIDES TO THE BACK (USE HOLES PROVIDED). ONCE THE 3 COMPONENTS ARE SCREWED IN PLACE, SLIDE IN THE 8MM THICK BASE.

INSERT THE FINAL SIDE AND YOU WILL HAVE A 4 SIDED BEDROOM DRAWER BOX. ATTACH WITH THE 45MM SCREWS (LONGEST ONES) PROVIDED (USING THE PRE-DRILLED HOLES) AND YOUR DRAWER BOX IS ASSEMBLED.

TIPS ON FITTING BALL BEARING RUNNER BEDROOM DRAWERS

FOR EXAMPLE IF YOUR DRAWER BOX HEIGHT IS 150MM OR 200MM,

THEN MEASURE 41MM UP FROM THE INSIDE BOTTOM OF YOUR UNIT, STRIKE A LINE FROM FRONT TO BACK OF YOUR UNIT - 41MM HIGH.

TAKE SIDE RUNNER ROLLER AT TOP FRONT, PLACE RUNNER IN LINE WITH EDGE OF YOUR UNIT FRONT WITH HOLES OVER STRIKE LINE (CENTRE OF HOLES IN LINE WITH STRIKE LINE)

SCREW THE RUNNER IN PLACE

PLACE THE DRAWER BOX INTO THE UNIT

DRILL 2 X 8MM TO 10 MM HOLES IN FRONT OF THE DRAWER BOX. PLACE TWO STICKY PADS ON FRONT OF DRAWER BOX AND TAKE YOUR OWN FACIA - EYE UP YOUR FACIA AND PLACE ON. TAKE A SCREW AND A WASHER AND SCREW THROUGH, LIGHTLY, YOUR 8MM TO 10 MM HOLES, MAKING SURE YOU HAVE RIGHT LENGTH OF SCREW. ONCE FACIA IS IN LINE AND TO YOUR LIKING, FASTEN SCREWS UP TIGHTLY.

THIS WILL GIVE YOU SOME ADJUSTMENT FOR ALIGNMENT OF YOUR FACIA. THEN PUT TWO ADDITIONAL SCREWS TO HOLD DRAWER FACIA SECURELY ON THE DRAWER BOX

IF YOU HAVE MORE THAN ONE DRAWER BOX IN ONE UNIT, ONCE YOU HAVE DONE THE AFORE MENTIONED, MARK ON SIDE OF UNIT, WHERE YOUR FACIA TOP IS.

MEASURE 41MM UP STRIKE LINE. REPEAT FOR EACH ADDITIONAL DRAWER BOX, AS AFORE MENTIONED THIS WILL GIVE YOU PROPER CLEARANCE FOR EACH DRAWER BOX

A 150MM HIGH DRAWER BOX CAN BE USED FOR A 200MM PLUS HIGH DRAWER FACIA AND PRO RATA FOR ANY OTHER HEIGHT DRAWER BOX, E.G. 200MM HIGH BOX, 250MM FACIA. FACIA MUST ALWAYS BE AT LEAST 50MM HIGHER THAN DRAWER BOX HEIGHT

WE SUPPLY 2 X 3MM PACKERS, IF YOU HAVE 15MM CARCASS. IF YOU USE GRUB SCREWS FOR RUNNERS, YOU WILL NEED TO DRILL 5MM HOLES WHERE SCREWS SHOULD GO.

ONLY FOR BALL BEARING RUNNERS

THE RELEASE ON SIDE BALL BEARING RUNNERS

